



TRIBO 10

Liquid product, used to polish and brighten, for tumbling or vibrator applications and in ultrasonic processes.

COMPATIBILITY:

- Gold
- Silver
- Brass
- Stainless steel

INGREDIENTS:

- Strong alkalis, surfactants, phosphates
- Chelating agents, anti-corrosion agents

No NTA

PHYSICAL AND CHEMICAL DATA:

- pH concentrated: 9.9
- pH (1%): 9.8
- Density: 1.012
- Surface tension: 28.8 mN/m

INSTRUCTIONS FOR USE:

Optimum use conditions may be affected by the quality of the water used in the baths, as well as the type and quantity of contaminants.

- Concentration: 1 to 2%
- Temperature: 20 to 25°C (68 to 77°F)
- Time: 30 min. to 2 hours

BENEFITS:

- Fast results on ferrous metals
- Non-corrosive and non-toxic
- Very high brightening effect
- Low concentration for use

15/01/20

STORAGE CONDITIONS:

- Keep the recipient hermetically sealed between 5°C and 40°C (41°F and 104°F) in a dry place.
- Always keep in packaging made from the same material as the original packaging.



If you have any questions, please contact our Application Centre on: +41 22 365 46 66

